

NEO

RAZE SIZE CHART



YOUR HEAD SIZE

CENTIMETERS

HELMET
SIZE

57-58

M

59-60

L

61-62

XL

HOW TO MEASURE

A HEAD CIRCUMFERENCE

Using a measuring tape, measure the head circumference at the head's widest point, just above the eyebrows and the ears.

